

Road Doctor® 3 Viewer installation

1. Download and run setup package, Version number will vary



2. Wait until windows extracts installation files to your computer



3. Click Next



4. Read license terms. To install Road Doctor® Viewer, you need to accept terms. Click Next

🚽 Road Doctor Viewer - InstallShield	l Wizard		×
License Agreement			DD
Please read the following license agr	reement carefully.		RL
These License Terms constitute legal entities on whose behalf s software based on a Roadscann Roadscanners Oy, a corporat ("ROADSCANNERS") with its princ Rovaniemi, Finland.	an agreement be uch individuals are ers software lice ion organised u ipal place of busi	tween the indivio e acting, using Ro nse (hereinafter nder the laws ness at Varastotie	duals or any A padscanners "USER") and of Finland a 2, FI-96100
Roadscanners Software ("SOFTW, following software product of I	ARE") shall mean t Roadscanners, inc	the object code luding online and	copy of the d hard-copy 🗸
I accept the terms in the license agree	eement		Print
I do not accept the terms in the licen	nse agreement		
nstallShield			

5. Change Destination Folder if needed. Click Next

🛃 Road Do	octor Viewer - InstallShield W	/izard	h (14604)	×
Destinati Click Nex	i on Folder kt to install to this folder, or clic	k Change to insta	all to a different folde	RD
D	Install Road Doctor Viewer to C:\Program Files\RD Apps\Rd	ad Doctor Viewer	1	<u>C</u> hange
InstallShield -				
		< <u>B</u> ack	<u>N</u> ext >	Cancel

6. Press "Install". Depending on your Windows settings, you might be asked about user rights for the setup.

eady to Install the Program		
The wizard is ready to begin insta	allation.	R
If you want to review or change a exit the wizard.	any of your installation settings, dick Back. Click Can	cel to
Current Settings:		
Setup Type:		
Typical		
Destination Folder:		
C:\Program Files\RD Apps\Rc	oad Doctor Viewer\	
User Information:		
Name: kurssi		
Company: Microsoft		
1		

7. Wait until installation completed. The installation takes time because installation package runs an optimization routine for Road Doctor. You can monitor the process from the windows task manager (mscorsvw.exe - .NET runtime optimization service)

🛃 Road Do	octor Viewer - InstallShield V	Vizard	<u></u>		×
Installin	g Road Doctor Viewer				
The pro	gram features you selected ar	e being installed.			RU
P	Please wait while the Install may take several minutes.	Shield Wizard installs	Road Doctor View	wer. This	
	Status:				
	Copying new files				
InstallShield	2				
		< Back	Next >	Can	cel

8. Press Finish. If "Launch the Program" is checked, the program will start. If not, start from **Start** menu. If the Program icon is not visible, start writing the name of the program.



9. In other cases, start program from the Windows **Start** menu, or start by writing the name of the program in start menu, if the name is not visible in the list. At first, the project Group list will be empty, unless you are updating the program. In the example below three projects have been added to Project Group.



RD = FILE = HOME	VIEW PROJECT GROUP TOOLS	ROAD DOCTOR	VIEWER version 3.5.101(c) 2000-2021 Roadscanners		- 🗆 × & @
Copy 🤊 Undo Paste (P Redo Cut X Delete	Map Frame ☐ Coordinates ⓓ Video Frame Image: Cross Section ➡ Point Cloud \$ Single Scan View	Refresh View		Linked Views ♥ GPR Processing Mode	l Arrange View Windows ▼ Image: Visual Style ▼ Image: Provide the state of the s
Edit	Display		Settings	View	Window
Edit Refresh E) Project Project Group	FE K [편] 《 pand Tree Undo Last Undock				^
● ▲ SSD VAR-ELY					
Project Name: 4					
Line Name:					
Data Type: F	roject=Road				~
Data Name:	rdn 🗸	ROADSCANNER	RS BEYON TH SURFAC	CLICK TO LEARN MOR	E ABOUT ROADSCANNERS SOFTV